



To open, simply press on the little spot on the rim of the lid with one finger or the palm of your hand.



Easy to open, no twisting or turning. Just lift the lid up.



To reseal the box, simply press the middle of the lid

One hand box

The One Hand Box is ideal for children, the elderly, the disabled or anyone with weak hands.

Easy to open, no twisting or turning.

The One Hand Box is very easy to use. To open, simply press on the little spot on the rim of the lid with one finger or the palm of your hand.

To reseal the box, simply press the middle of the lid.

- Available in 3 sizes: 0.75 l , 1.35 l, 2.00 l
- Dishwasher safe
- Made of S:A:N, an environmentally friendly material
- Approved for storage of foods
- Keeps sugar, coffee, biscuits etc fresh. Ideal for beads, cotton reels, puzzles and other small items

rikacare.dk



DS/EN ISO 9001 CERTIFIED

RIKA PLAST AS, Saunte Bygade 12, 3100 Hornbaek, Denmark
Phone + 45 4975 0130 fax + 45 4975 0201, rika@rika.dk, rikacare.dk